





clíc adjustments

Version 1.4


Afmontering af låge
Dismounting of door
 Demontage der Tür




Montering af låge
Mounting the door
 Montage der Tür




Justering af låge
Adjusting the door
 Justierung der Tür




Afmontering af Center låge
Dismounting of Center door
 Demontage der Center Tür




Montering af Center låge
Mounting the Center door
 Montage der Center Tür




Justering af klapholder
Adjusting the flap stay
 Justierung der Klappenhalter




Smøring
Lubrication
 Schmierung




Afmontering af skuffe
Dismounting of drawer
 Demontage der Schublade




Montering af skuffe
Mounting the drawer
 Montage der Schublade




Justering af skuffe
Adjusting the drawer
 Justierung der Schublade



CD inddeling
CD subdivision
 CD Einteilung



BluRay, PS3/PSP ind-
 deling
*BluRay, PS3/PSP sub-
 division*
 BluRay, PS3/PSP Ein-
 teilung



DVD inddeling
DVD subdivision
 DVD Einteilung

